

DIY INSTRUCTION

Transfer with Iron



Steps:

1. Prepare an Iron board or a flat timber board
2. Place the fabric onto the board, iron to remove wrinkles
3. Place the printed film on the fabric make sure the graphic face up
4. Switch off the steam function of Iron (140 -150°C)
5. Press the Iron for 15-20 seconds then move away, for big graphic, slowly move the iron back and forth (with even pressure).
6. Peel off the PET film **only when the surface cool down.**
7. In case of incomplete transfer, place the PET film back or use a baking paper to cover the print and Iron press another 5-10 seconds.
8. Remove the film or paper.

Tip: Iron the print onto your garment using a hard surface (like a tile floor, piece of wood, or a cookie sheet, etc).

For the longest life of your heat transfer: wash inside out in cold water with no fabric softener or bleach and tumble dry.

Note: This product will not adhere to nylon garments or products.

Washable after 24hours

DanzoTM
Trusted Professional Wear